



NOTES:

POSITION YOUR MAILBOX 41" TO 45" ABOVE GROUND LEVEL

PLACE YOUR MAILBOX 6" TO 8" BACK FROM CURB. IF YOU DO NOT HAVE A RAISED CURB, USE THE EDGE OF THE BITUMINOUS.

HAVE BOX EXTENDED AS FAR IN FRONT OF SUPPORT POST AS POSSIBLE (THIS PREVENTS POSSIBLE SNOW PLOW DAMAGE)

ADDRESS MUST BE ON THE SIDE OF MAILBOX FROM WHICH CARRIER APPROACHES IN LETTERS ABOUT 1" HIGH (OR ON FRONT WHERE BOXES ARE GROUPED)